



EU DECLARATION OF CONFORMITY



Copreci S.Coop.
Araba Ibilbidea, 3
E-20550 Aretxabaleta-GIPUZKOA (Spain)
Tlfn: + 34 943034499

Declare under our sole responsibility that the product:

Model	PIN AENOR	Description
GE 22400	99CT954	Manually operated valve for gas burning appliances

To which this declaration relates is in compliance with the regulation UE 2016/426 of the European parliament on appliances burning gaseous fuels

And comply with the standards listed below

- EN 1106: Manually operated taps for gas burning appliances
- EN 13611:2016: Safety and control devices for burners and appliances burning gaseous and/or liquid fuels. General requirements

The notified body AENOR (0099) (C/Génova, 6, 28004 Madrid-España) performed the evaluation of the conformity procedure with the type based on the product quality assurance in accordance with the provisions of module E and issued the A01/002180 certificate, on 24/05/2018 and valid until 24/05/2021

This certificate is valid from 14/11/2019

Alaitz Gonzalez
Copreci, S. Coop.
Laboratory Manager

Instructions for installation of the product subject to this declaration:

“Consult the instructions before using this device. Installation must meet the regulations in force”

1. Technical information for the installer

INSTRUCTIONS	
MODEL	GE 22400
GROUP	1
PURPOSE	Built in
CHARACTERISTICS	Maximum pressure: 100 mB Reference flow: 0.2 m ³ /h air with 1 mbar. pressure drop Nominal diameter: <6 T ^a max.: 150°C T ^a min.: 0°C
NUMBER OF MECHANICAL CYCLES	10000 cycles
MOUNTING POSITION	multiposition
CONNECTIONS	Ø16 bracket
TORQUE OF FITTING (max)	3 Nm
PUSHING FORCE (max)	30 N
TURNING TORQUE OF SPINDLE (max)	0.4 Nm
PRESSURE RANGE	8 to 100 mB
GASES OF USE	1st, 2nd y 3th families

2. Instruction manual for use and maintenance intended for the user.

- *Component does not require any maintenance. Washing the thermostat with soapy water or other products may involve deterioration.*
- *Do not pour liquids in the component.*
- *The appliance can only be switched on in the user's presence.*
- *The component must not be manipulated or repaired in any way*
- *In case of malfunction, the manufacturer of the appliance and its specialized technical service carries out the replacement of the component.*
- *The transformation of the component to use another gas will be carried out by personnel authorized by the manufacturer of the appliance*
- *The installer must check the suitability of the component functions for the intended use*